

## Thermostatic cell holding stage PEC-T10

- Flat stage cell holder is requirement.
- Temperature controlled range from 0 to 80 °C
- Piezoelectric thermo sensor.

### Operation is very easy as following

- 1) Turn on the switch
- 2) Set a temperature as you expected by pressing buttons with direction mark of up and down.

### Measure for safety

- 1) The glass fuse (3A) prevents from an over-current.
- 2) When the stage temperature reaches 85 °C, the power is shut down automatically.



*Peccell Technologies, Inc.*  
1614 Kurogane-cho, Aoba, Yokohama,  
Kanagawa, 225-8502 Japan  
TEL +81-45-974-5656, FAX +81-45-974-5657  
E-mail: eigyou@peccell.com  
<http://www.peccell.com/>